

## REASSEMBLY

### 1. SELECT PISTON ROD


If the band is OK with piston rod stroke not within the standard value, select a new piston rod.

HINT:

There are 5 different lengths for piston rod.


**Piston rod length: mm (in.)**

77.65 (3.057)	79.90 (3.146)
78.40 (3.087)	–
79.15 (3.116)	–




### 2. ASSEMBLE 3RD COAST BRAKE PISTON

- (a) Install the retainer, compression spring and piston to the piston rod.



- (b) Firmly hold down the piston, then compress the compression spring.  
(c) Install the E-ring.



### 3. INSTALL 3RD COAST BRAKE PISTON OIL SEAL RING

- (a) Coat the oil seal ring with ATF.  
(b) Install the oil seal ring to the piston groove, then snug it down by squeezing its ends together.

**NOTICE:**

**Do not spread the ring ends more than necessary.**