

## PROBLEM SYMPTOMS TABLE

Proceed to the reference page shown in the table below for each malfunction symptom and troubleshoot each circuit.

### HINT:

The theft deterrent system is based on the premise that the door lock control system and the wireless door lock control system are operating normally. Check these systems first before troubleshooting the theft deterrent system.

Symptom	Suspected Area	See Page
Theft deterrent system cannot be set	1. Security indicator circuit 2. ECU power source circuit 3. Unlock warning switch circuit (w/ smart key system) Unlock warning switch circuit (w/o smart key system) 4. Door unlock detection switch circuit 5. Back door key lock and unlock switch 6. Door courtesy switch circuit 7. Back door courtesy switch circuit 8. Engine hood courtesy switch circuit	<a href="#">05-3105</a> <a href="#">05-3111</a> <a href="#">05-3010</a> <a href="#">05-3043</a> <a href="#">05-2564</a> <a href="#">05-2798</a> <a href="#">05-2596</a> <a href="#">05-2608</a> <a href="#">05-3108</a>
Security indicator dose not blink when theft deterrent system is set	1. Security indicator circuit	<a href="#">05-3105</a>
Alarm sounding state cannot be canceled when ignition switch is turned ON-OFF 10 times within 15 seconds	1. Ignition switch circuit 2. Unlock warning switch circuit (w/ smart key system) Unlock warning switch circuit (w/o smart key system)	<a href="#">05-3113</a> <a href="#">05-3010</a> <a href="#">05-3043</a>
Theft deterrent system can be set even when any door is open	1. Door courtesy switch circuit	<a href="#">05-2596</a>
Horn (low pitched, high pitched) dose not sound while theft deterrent system is in warning operation	1. Horn (low pitched, high pitched) circuit	<a href="#">05-3125</a>
Headlamps do not flash while theft deterrent system is in warning operation (Except for Europe)	1. Headlamp circuit	<a href="#">05-1369</a>
Taillamps do not flash while theft deterrent system is in warning operation (Except for Europe)	1. Taillamp circuit	<a href="#">05-1369</a>
Hazard warning lamps do not flash while theft deterrent system is in warning operation	1. Hazard warning circuit	<a href="#">05-1369</a>
Room lamp dose not light up while theft deterrent system is in warning operation	1. Room lamp circuit	<a href="#">05-1369</a>
Security horn dose not sound while theft deterrent system is not set (Except for Europe)	1. Security horn circuit	<a href="#">05-3120</a>
Headlamps flash even when theft deterrent system is not set (Except for Europe)	1. Headlamp circuit	<a href="#">05-1369</a>
Taillamps flash even when theft deterrent system is not set (Except for Europe)	1. Taillamp circuit	<a href="#">05-1369</a>
Hazard warning lamps flash even even theft deterrent system is no set	1. Hazard warning switch circuit	<a href="#">05-1369</a>
Room lamp lights up even even theft deterrent system is not set	1. Room lamp circuit	<a href="#">05-1369</a>
Theft warning siren sounds even when theft deterrent system is not set (Europe only)	1. Theft warning siren circuit	<a href="#">05-3111</a>
Intrusion (theft warning) sensor dose not detect any moving object is while theft deterrent system is set (Europe Only)	1. Instrution sensor circuit	<a href="#">05-3123</a>
Intrusion (theft warning) sensor sets off alarm while theft deterrent system is not set or there is nothing moving inside vehicle with theft deterrent system set (Europe only)	1. Instrution sensor circuit	<a href="#">05-3123</a>

**DIAGNOSTICS** – THEFT DETERRENT SYSTEM

Intrusion (theft warning) sensor OFF switch dose not operate (Europe only)	1. Instrution sensor circuit	<a href="#">05-3123</a>
Intrusion (theft warning) sensor OFF switch continues operating (Europe only)	1. Instrution sensor circuit	<a href="#">05-3123</a>