


## OVERHAUL


### HINT:

Use high-temperature grease to lubricate the bearings and gears when assembling the starter.




#### 1. REMOVE STARTER YOKE ASSY

- (a) Remove the nut and disconnect the lead wire from the magnetic switch terminal.
- (b) Remove the 2 bolts and pull out the starter yoke together with the armature from the magnetic switch.
- (c) Remove the O-ring from the starter yoke.




#### 2. REMOVE MAGNET STARTER SWITCH ASSY

- (a) Remove the 2 screws, and separate the starter switch and starter housing.
- (b) Remove the O-ring, starter clutch, return spring, idler gear and bearing.
- (c) Using a magnetic finger, remove the steel ball from the clutch shaft hole.



#### 3. REMOVE END COVER

- (a) Remove the 2 screws and end cover.




#### 4. REMOVE STARTER BRUSH HOLDER ASSY

- (a) Using a screwdriver, hold the spring back and disconnect the brush from the brush holder. Disconnect the 4 brushes, and remove the brush holder.
- (b) Disconnect the brushes and remove the brush holder.

#### 5. REMOVE STARTER ARMATURE ASSY

#### 6. INSPECT STARTER ARMATURE ASSY


- (a) Check the commutator for contamination and burns on its surface. If the surface is dirty or burnt, correct it with sandpaper (#400) or a lathe.



- (b) Check if the commutator has an open circuit.  
 (1) Measure the resistance between the segments of the commutator.

**Standard: Below 1 Ω**


If the result is not as specified, replace the armature assy.



- (c) Check if the commutator is grounded.  
 (1) Measure the resistance between the commutator and armature coil core.

**Standard: 10 kΩ or higher**


If the result is not as specified, replace the armature assy.



- (d) Check the commutator circle runout.  
 (1) Place the armature on the V-blocks.  
 (2) Using a dial gauge, measure the circle runout.

**Maximum circle runout: 0.05 mm (0.0020 in.)**

If the circle runout is greater than the maximum, correct it with sandpaper (#400) or replace the armature assy.



- (e) Using vernier calipers, measure the commutator diameter.

**Specified diameter:**


**1.4 kW type**

Standard	30.0 mm (1.181 in.)
Minimum	29.0 mm (1.142 in.)

**2.0 kW type**

Standard	35.0 mm (1.378 in.)
Minimum	34.0 mm (1.339 in.)

If the diameter is less than the minimum, replace the armature assy.



- (f) Measure the undercut depth of the commutator.

**Specified depth:**

**1.4 kW type**

Standard	0.6 mm (0.024 in.)
Minimum	0.2 mm (0.008 in.)

**2.0 kW type**


Standard	0.7 mm (0.028 in.)
Minimum	0.2 mm (0.008 in.)

If the undercut depth is less than the minimum, correct it with a hacksaw blade.

- (g) Inspect the bearings.

**OK: Rotates smoothly**

If necessary, replace the armature assy.




## 7. INSPECT STARTER YOKE ASSY

- (a) Check the field coil resistance.

- (1) Using an ohmmeter, measure the resistance between the lead wire and both brushes.

**Standard: Below 1 Ω**

If the result is not as specified, replace the starter yoke assy.




- (b) Inspect the shunt coil resistance.

- (1) Using an ohmmeter, measure the resistance between the shunt coil terminals.

**Standard: 1.5 to 1.9 Ω at 20°C (68°F)**

If the resistance is not as specified, replace the starter yoke assy.



**8. INSPECT BRUSH**

- (a) Using vernier calipers, measure the length of the both brushes.

**Specified brush length:**


**1.4 kW type**

Standard	15.5 mm (0.610 in.)
Minimum	8.5 mm (0.335 in.)

**2.0 kW type**

Standard	15.0 mm (0.591 in.)
Minimum	9.0 mm (0.354 in.)

If the length is less than the minimum, replace the brush holder assy and starter yoke assy.




**9. INSPECT STARTER BRUSH HOLDER ASSY**

- (a) Check the brush insulation.  
(1) Check the resistance between the positive (+) and negative (-) brush holders.

**Standard: 10 kΩ or higher**

If the result is not as specified, repair or replace the brush holder assy.



- (b) Using a pull scale, measure the brush spring load.

**Specified spring load:**


**1.4 kW type:**

Standard	17.6 to 23.5 N (1.8 to 2.4 kgf, 4.0 to 5.3 lbf)
Minimum	11.8 N (1.2 kgf, 2.7 lbf)

**2.0 kW type:**

Standard	21.5 to 27.5 N (2.2 to 2.8 kgf, 4.9 to 6.2 lbf)
Minimum	12.7 N (1.3 kgf, 2.9 lbf)


If the spring load is less than the minimum, replace the brush springs.



### 10. INSPECT STARTER CLUTCH SUB-ASSY

- (a) Check that the starter clutch operates as shown in the illustration.

If the starter clutch does not operate, replace clutch assy.




### 11. INSPECT MAGNET STARTER SWITCH ASSY

- (a) Check if the pull-in coil has an open circuit.  
 (1) Using an ohmmeter, measure the resistance between terminals 50 and C.

**Standard: Below 1  $\Omega$**

If the result is not as specified, replace the magnetic switch assy.



- (b) Check if the hold-in coil has an open circuit.


- (1) Using an ohmmeter, measure the resistance between terminal 50 and the switch body.

**Standard: Below 2  $\Omega$**

If the result is not as specified, replace the magnetic switch assy.

### 12. INSTALL STARTER ARMATURE ASSY

- (a) Apply grease to the armature bearings.  
 (b) Insert the armature into the yoke.




### 13. INSTALL STARTER BRUSH HOLDER ASSY

- (a) Place the brush holder on the starter yoke.  
 (b) Using a screwdriver, hold the brush spring back and connect the brush into the brush holder. Connect the 4 brushes.

#### NOTICE:

**Check that the positive lead wires are not grounded.**

- (c) Install a new O-ring to the groove of the starter yoke.




- (d) Install the end cover to the starter yoke with the 2 screws.

**Torque:**


**1.5 N·m (15 kgf·cm, 13 in.·lbf) for 1.4 kW type**

**3.8 N·m (39 kgf·cm, 34 in.·lbf) for 2.0 kW type**




**14. INSTALL MAGNET STARTER SWITCH ASSY**

- (a) Apply grease to the steel ball.  
 (b) Insert the steel ball into the clutch shaft hole.  
 (c) Apply grease to the return spring.




- (d) Insert the return spring into the magnetic switch hole.



- (e) Place these parts on the starter housing:

- (1) A new O-ring.  
 (2) The starter clutch.  
 (3) The idler gear.  
 (4) The bearing.




- (f) Install the starter housing to the magnetic switch with the 2 screws.


**Torque:**

**5.9 N·m (60 kgf·cm, 52 in.·lbf) for 1.4 kW type**

**9.3 N·m (95 kgf·cm, 82 in.·lbf) for 2.0 kW type**

**15. INSTALL STARTER YOKE ASSY**

- (a) Install a new O-ring to the groove of the starter yoke.
- (b) Align the protrusion of the starter yoke with the groove of the magnetic switch, and install the starter yoke and armature.



- (c) Install the starter yoke and armature with the 2 bolts.

**Torque:****5.9 N·m (60 kgf·cm, 52 in.·lbf) for 1.4 kW type****9.3 N·m (95 kgf·cm, 82 in.·lbf) for 2.0 kW type**

- (d) Connect the lead wire to terminal C with the nut.

**Torque: 5.9 N·m (60 kgf·cm, 52 in.·lbf)**