


REPLACEMENT

1. DISCONNECT BATTERY NEGATIVE TERMINAL
2. REMOVE ENGINE UNDER COVER NO.1
3. REMOVE AIR CLEANER INLET NO.1
4. DRAIN ENGINE COOLANT (See page 16-8)
5. REMOVE V-BANK COVER
6. REMOVE INTAKE AIR CONNECTOR PIPE (14-26)
7. DISCONNECT RADIATOR HOSE NO.1
8. DISCONNECT RADIATOR HOSE NO.2
9. DISCONNECT OIL COOLER INLET TUBE NO.1
10. DISCONNECT OIL COOLER OUTLET TUBE NO.1
11. REMOVE AIR CLEANER ASSY (See page 14-26)



12. REMOVE RADIATOR AND FAN ASSEMBLY

- (a) Disconnect the cooling fan ECU connector.
- (b) Remove the 2 nuts and 2 radiator upper supports.
- (c) Remove the radiator and fan assembly.
- (d) Remove the 2 radiator lower supports.

13. REMOVE FAN ASSY

- (a) Disconnect the radiator reservoir hose from the radiator.
- (b) Remove the 6 bolts and fan.

14. INSTALL FAN ASSY

- (a) Install the fan with the 6 bolts.

Torque: 5.0 N·m (50 kgf·cm, 44 in.·lbf)

- (b) Connect the radiator reservoir hose to the radiator.

15. INSTALL RADIATOR AND FAN ASSEMBLY

- (a) Install the 2 radiator lower supports to the radiator.
- (b) Attach the 2 radiator lower supports on the radiator to the body bracket.
- (c) Install the radiator and fan assembly with the 2 radiator upper supports and 2 nuts.

Torque: 13.5 N·m (138 kgf·cm, 10 ft·lbf)

- (d) Connect the cooling fan ECU connector.

16. INSTALL AIR CLEANER ASSY (See page 14-26)

17. INSTALL AIR CLEANER INLET NO.1

18. REFILL ENGINE COOLANT (See page 16-8)

19. CHECK FOR ENGINE COOLANT LEAKS (See page 16-1)

20. INSTALL ENGINE UNDER COVER NO.1

21. CONNECT BATTERY NEGATIVE TERMINAL

22. POWER WINDOW CONTROL SYSTEM INITIALIZE (See page 01-20)

23. FRONT POWER SEAT CONTROL SYSTEM INITIALIZE (See page 01-20)

24. BACK GUIDE MONITOR SYSTEM INITIALIZE (See page 01-20)