



## INSPECTION

### INSPECT STABILIZER BAR LINK BALL JOINT FOR ROTATION CONDITION

- (a) Flip the ball joint stud back and 4 – 5 times before installing the nut.
- (b) Using a torque wrench, turn the stud continuously one turn every 2–4 seconds and take the torque reading on the 5th turn.

#### Turning torque:

**0.05 – 1.5 N·m (0.5 – 15 kgf·cm, 0.4 – 13 in.·lbf)**