


PASSENGER DOOR ECU POWER SOURCE CIRCUIT

CIRCUIT DESCRIPTION

This circuit supplies power to operate the passenger door ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT FUSE (MPX-IG, AM1, P DOOR, MPX-B1)


- (a) Remove the MPX-IG and AM1 fuses from the driver side J/B.
(b) Remove the P DOOR and MPX-B1 fuses from the passenger side J/B.
(c) Measure the resistance.

Standard: Below 1 Ω

NG REPLACE FUSE

OK

2 INSPECT RELAY (D-IG1)



- (a) Remove the D-IG1 relay from the driver side J/B.
(b) Check the resistance.


Standard:

| Tester Connection | Specified Condition |
|-------------------|---|
| 3 - 5 | 10 kΩ or higher |
| 3 - 5 | Below 1 Ω (when battery voltage is applied to terminals 1 and 2) |

NG REPLACE RELAY

OK

3 CHECK WIRE HARNESS (PASSENGER DOOR ECU - BODY GROUND)



- (a) Disconnect the F17 ECU connector.
(b) Check the voltage and resistance of the wire harness side connectors.

Standard:

| Tester Connection | Condition | Specified Condition |
|----------------------------|--------------------|---------------------|
| DF17-1 (GND) - Body ground | Constant | Below 1 Ω |
| F17-4 (CPUB) - Body ground | Constant | 10 to 14 V |
| F17-6 (BDR) - Body ground | Constant | 10 to 14 V |
| F17-5 (SIG) Body ground | Ignition switch ON | 10 to 14 V |

NG REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-1289)