

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Both right and left mirrors do not operate.	1. Power source circuit (Driver side J/B ECU) 2. Mirror switch circuit If the 2 suspected areas above is functioning normally, replace the driver side J/B ECU.	05-2097 05-2100
Driver side mirror does not operate.	1. Power source circuit (Driver door ECU) 2. Mirror motor circuit 3. Mirror position sensor circuit (w/memory) 4. Mirror switch circuit If the 4 suspected areas above is functioning normally, replace the driver door ECU and driver side J/B ECU.	05-2092 05-2107 05-2112 05-2100
Passenger side mirror does not operate.	1. Power source circuit (Front passenger door ECU) 2. Mirror motor circuit 3. Mirror position sensor circuit (w/memory) 4. Mirror switch circuit If the 4 suspected areas above is functioning normally, replace the passenger door ECU and driver side J/B ECU.	05-2094 05-2107 05-2112 05-2100
Retract mirror does not operate.	1. Retract mirror switch 2. Retract motor circuit If the 2 suspected areas above is functioning normally, replace the driver side J/B ECU and malfunctioning door ECU.	05-2104 05-2110
Driving position memory system does not operate.	1. Mirror position sensor circuit 2. Driving position memory switch circuit (w/memory) If the 2 suspected areas above is functioning normally, replace the driver seat ECU* and malfunctioning door ECU.	05-2112 05-2314
Mirror defogger system does not operate.	1. Mirror defogger circuit If the suspected area above is functioning normally, replace the malfunctioning door ECU.	05-2116
Automatic glare-resistant EC mirror system does not operate.	1. Electrochromic mirror circuit If the suspected area above is functioning normally, replace the malfunctioning door ECU.	05-2114

HINT:

*: After replacing the driver seat ECU, initialize the front power seat (see page 05-2280).