

## INSTALLATION

Installation is in the reverse order of removal (See page SA-91).

HINT:

After installation, check the speed sensor signal (See page DI-343), and rear wheel alignment (See page SA-10).