

HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

Use this procedure to troubleshoot the climate control seat system.

1 VEHICLE BROUGHT TO WORKSHOP



2 CUSTOMER PROBLEM ANALYSIS CHECK AND SYMPTOM CHECK (See page 05-2446)



3 CHECK COMMUNICATION FUNCTION OF LARGE-SCALE MULTIPLEX COMMUNICATION SYSTEM (BEAN)

- (a) Use the intelligent tester II to check for normal function of the multiplex communication system.
- (1) (ECU unconnected, communication line malfunctioning) Without code outputs, proceed to A.
 - (2) (ECU unconnected, communication line malfunctioning) With code outputs, proceed to B.

B

Go to MULTIPLEX COMMUNICATION SYSTEM
(See page 05-3162)

4 CHECK FOR DTC

- (a) See for DTCs.



5 PROBLEM SYMPTOMS TABLE (See page 05-2455)

- (a) If the fault is not listed on the problem symptoms table, proceed to A.
- (b) If the fault is listed on the problem symptoms table, proceed to B.

B

Go to step 7

A

6 OVERALL ANALYSIS AND TROUBLESHOOTING

- (a) Terminals of ECU (see page 05-2447).
- (b) Inspection (see page 05-2506).



7 ADJUSTMENT, REPAIR OR REPLACE



8 CONFIRMATION TEST



END