

STEERING PAD SWITCH CIRCUIT

INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER

- (a) Connect the Intelligent Tester II to DLC3.
 (b) Turn the Ignition switch ON and push the Intelligent Tester II main switch ON.
 (c) Select the items below in the DATA LIST, and read the displays on the Intelligent Tester II.

SPAD:

Item	Measurement Item/ Display (Range)	Normal Condition
Audio Mode SW	Audio mode switch/ON or OFF	ON: Audio mode switch is pushed OFF: Audio mode switch is not pushed
Audio Volume Up SW	Audio volume UP switch/ ON or OFF	ON: Audio volume UP switch is pushed OFF: Audio volume UP switch is not pushed
Audio Volume Down SW	Audio volume DOWN switch/ ON or OFF	ON: Audio volume DOWN switch is pushed OFF: Audio volume DOWN switch is not pushed
Audio Selector Up SW	Audio selector UP switch/ ON or OFF	ON: Audio selector UP switch is pushed OFF: Audio selector UP switch is not pushed
Audio Selector Down SW	Audio selector DOWN switch/ ON or OFF	ON: Audio selector DOWN switch is pushed OFF: Audio selector DOWN switch is not pushed
Audio Volume Set SW	Audio volume set switch/ ON or OFF	ON: Audio volume set switch is pushed OFF: Audio volume set switch is not pushed
Spch Recognition Hook SW	Speech recognition hook switch/ ON or OFF	ON: Speech recognition hook switch is pushed OFF: Speech recognition hook switch is not pushed

OK

**PROCEED TO NEXT CIRCUIT INSPECTION
SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-1771)**

NG

REPLACE STEERING PAD SWITCH (SEE PAGE 67-25)