

<b>DTC</b>	<b>U0123</b>	<b>COMMUNICATION ERROR OF YAW RATE SENSOR</b>
------------	--------------	---

## CIRCUIT DESCRIPTION

This circuit detects the yaw rate of the vehicle and transmits its signal to the skid control ECU and distance control ECU.

DTC No.	DTC Detecting Condition	Trouble Area
U0123	While the dynamic laser cruise control is either preparing for operation or operating, if the ECM continuously receives a yaw rate sensor malfunction signal for a certain amount of time, distance control ECU sends a signal to the ECM to record this trouble code.	<ul style="list-style-type: none"><li>• Communication circuit</li><li>• Yaw rate sensor</li><li>• Cruise control ECU (Distance control ECU)</li><li>• ECM</li></ul>

## INSPECTION PROCEDURE

### HINT:

This circuit uses CAN for communication. Therefore, if there are any malfunctions in the communication circuit, one or more DTCs in the CAN communication system is/are output.

1	GO TO CAN COMMUNICATION SYSTEM (SEE PAGE 05-3306)
---	---