

LOCATION

For RHD vehicle, look at the same location on the opposite side of the vehicle

Theft Warning ECU

Gateway ECU

Driver Side J/B

- AM1 Fuse
- MPX-IG Fuse

Passenger Side J/B

- MPX-B1 Fuse
- D Door Fuse
- P Door Fuse
- RR Door LH Fuse
- RR Door RH Fuse

Driver Door Lock Assy

- Door Closer Motor
- Door Lock Motor
- Cam Position Switch
- Lock Position Switch
- Pawl Switch
- Half Latch Switch
- Full Latch Switch

Passenger Door ECU

Passenger Door Lock Assy

- Door Closer Motor
- Door Lock Motor
- Cam Position Switch
- Lock Position Switch
- Pawl Switch
- Half Latch Switch
- Full Latch Switch

Rear Door RH ECU

Rear Door Lock Assy RH

- Door Closer Motor
- Door Lock Motor
- Cam Position Switch
- Lock Position Switch
- Pawl Switch
- Half Latch Switch
- Full Latch Switch

Rear Door LH ECU

Driver Door ECU

Rear Door Lock Assy LH

- Door Closer Motor
- Door Lock Motor
- Cam Position Switch
- Lock Position Switch
- Pawl Switch
- Half Latch Switch
- Full Latch Switch