

REMOVAL

1. DRAIN ENGINE COOLANT
2. REMOVE OIL FILTER (See page LU-3)
3. DISCONNECT WATER BYPASS HOSES FROM OIL COOLER
4. REMOVE OIL COOLER
 - (a) Remove the union bolt and oil cooler.
 - (b) Remove the O-ring from the oil cooler.