

PROBLEM SYMPTOMS TABLE

HINT:

- Use the table below to help determine the cause of the problem symptom. The potential causes of the symptoms are listed in order of probability in the "Suspected Area" column of the table. Check each symptom by checking the suspected areas in the order they are listed. Replace parts as necessary.
- Inspect the fuses and relays related to this system before inspecting the suspected areas below.

NOTICE:

When replacing the skid control ECU, sensor, etc., turn the ignition switch OFF.

Symptom	Suspected Area	See Page
System operates when possibility of crash does not exist	1. Check installation condition of millimeter wave radar sensor 2. Cruise control ECU (distance control ECU) may detect possible crash objects, and system may activate even when vehicle does not collide with object	82-1 03-6
System does not operate when possibility of crash exists	1. Check installation condition of millimeter wave radar sensor 2. Check if inoperative conditions of system are met 3. As this system operates when cruise control ECU (distance control ECU) determines that crash is unavoidable, system may not have any malfunction	82-1 05-86 –
"PCS not Available Now" is displayed on multi-information display	1. Radiator grille or millimeter wave radar sensor is not clean 2. Millimeter wave radar sensor cannot detect possible crash objects because of bad weather 3. Overheating prevention function of seat belt control ECU operates	05-97 05-97 05-97
• Neither normal system code nor DTC is output • System does not operate normally even when normal system code is output and DTCs are not output	Power source circuit	05-122