

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during DTC check, check the circuit corresponding to the code in the table below. Proceed to the page given for the circuit.

DTC No. (See Page)	Detection Item	Trouble Area
B1205 (05-3164)	AFS ECU communication stop	<ul style="list-style-type: none"> • Wire harness • AFS ECU
B1211 (05-3168)	Driver door ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Driver door ECU
B1212 (05-3172)	Passenger door ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Passenger door ECU
B1213 (05-3176)	Tilt and telescopic ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Tilt and telescopic ECU
B1214, B1215 (05-3180)	<ul style="list-style-type: none"> • Door system communication bus malfunction (+B short) • Door system communication bus malfunction (GND short) 	<ul style="list-style-type: none"> • Wire harness • ECU (Door system bus)
B1216 (05-3189)	Rear right door ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Rear door RH ECU
B1217 (05-3193)	Rear left door ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Rear door LH ECU
B1219 (05-3197)	Rear seat switch communication stop	<ul style="list-style-type: none"> • Wire harness • Rear seat switch
B1248 (05-3201)	AVC-LAN communication impossible	<ul style="list-style-type: none"> • Wire harness • ECU (AVC-LAN system bus)
B1262 (05-3204)	A/C ECU communication stop	<ul style="list-style-type: none"> • Wire harness • A/C ECU
B1263 (05-3208)	Luggage room junction block ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Luggage room junction block ECU
B1266, B1267 (05-3212)	<ul style="list-style-type: none"> • Instrument panel system communication bus malfunction (+B short) • Instrument panel system communication bus malfunction (GND short) 	<ul style="list-style-type: none"> • Wire harness • ECU (Instrument system bus)
B1269 (05-3221)	Theft deterrent ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Theft deterrent ECU
B1271 (05-3225)	Combination meter ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Combination meter ECU
B1272 (05-3228)	Driver seat ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Driver seat ECU
B1273 (05-3232)	Sliding roof ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Moon roof control ECU
B1277 (05-3235)	Center cluster integration panel communication stop	<ul style="list-style-type: none"> • Wire harness • Center cluster integration panel
B1278 (05-3239)	Combination switch ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Combination switch ECU
B1279 (05-3243)	Rain sensor communication stop	<ul style="list-style-type: none"> • Wire harness • Rain sensor
B1281 (05-3245)	Airbag ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Airbag sensor assembly
B1283 (05-3249)	Driver side junction block ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Driver side junction block ECU

B1284 (05-3254)	Passenger side junction block ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Passenger side junction block ECU
B1285 (05-3258)	Steering pad switch communication stop	<ul style="list-style-type: none"> • Wire harness • Steering pad switch
B1291, B1292 (05-3261)	<ul style="list-style-type: none"> • Light control system communication bus malfunction (+B short) • Light control system communication bus malfunction (GND short) 	<ul style="list-style-type: none"> • Wire harness • ECU (Light control system bus)
B1294 (05-3270)	Immobilizer ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Transponder key ECU*1 • Steering lock ECU*2
B1296 (05-3277)	Front light ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Front light ECU
B1297 (05-3282)	Clearance sonar ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Clearance sonar ECU
B1298 (05-3286)	Rear right seat ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Rear RH seat ECU
B1299 (05-3290)	Rear left seat ECU communication stop	<ul style="list-style-type: none"> • Wire harness • Rear LH seat ECU

*1: w/o Smart key system

*2: w/ Smart key system

HINT:

When "+B or GND short malfunction of communication bus" DTCs (B1214, B1215, etc.) are detected at the same time as "communication stop" DTCs (B1211, B1212, etc.), please repair the "+B or GND short malfunction of communication bus" DTCs first.