


[illegible]

INSPECTION PROCEDURE

1 INSPECT FUSE (RR ECU-B)



- (a) Remove RR ECU-B fuse from Luggage Room J/B.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:


Tester Item	Condition	Specified Condition
RR ECU-B	Always	Below 1 Ω

NG

CHECK FOR SHORT IN ALL HARNESSES AND COMPONENTS CONNECTED TO FAILURE FUSE (RR ECU-B)

OK

2 INSPECT REAR AIR CONDITIONING AMPLIFIER (R-B - BODY GROUND)



- (a) Remove the rear A/C amplifier Assy and disconnect the connector.
- (b) Measure the voltage according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A48-3 (R-B) - Body Ground	Always	10 to 14 V

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR (REAR AIR CONDITIONER AMPLIFIER - BATTERY)

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-778)