

PROBLEM SYMPTOMS TABLE

Check the circuits for each problem symptom in the order given in the table below, and proceed to the relevant troubleshooting page.

Symptom	Suspected area	See page
Entirely inoperative (Self check does not function).	1. Power source of clearance warning ECU circuit 2. Clearance warning ECU Assy	05-2258 67-30
Entirely inoperative (Self check functions normally).	1. Clearance sonar main switch circuit 2. Clearance warning ECU Assy	05-2261 67-30
Detection can be done, but the detected condition is not displayed on the multi-information display.	1. Combination meter system 2. Clearance warning ECU Assy	05-2148 67-30
Detection can be done, but the detected condition is not displayed on the multi-display.	1. LEXUS navigation system 2. Clearance warning ECU Assy	05-1749 67-30
Although detection can be done, no buzzer sounds.	1. Clearance warning buzzer No.1 circuit 2. Clearance warning buzzer No.2 circuit 3. Clearance warning ECU Assy	05-2264 05-2267 67-30
Detection can be done when the shift position is in P, but not otherwise.	1. ECM 2. Clearance warning ECU Assy	05-7 67-30
Detection can be done although the vehicle speed is 10 km/h (6 mph) or more.	1. Combination meter system 2. Clearance warning ECU Assy	05-2148 67-30
Detection can be done although the engine revolution is 3,000 rpm or more.	1. ECM 2. Clearance warning ECU Assy	05-7 67-30