



ROOM TEMPERATURE SENSOR INSPECTION

1. LHD models:

REMOVE INSTRUMENT PANEL PAD LOWER

2. RHD models:

REMOVE SWITCH BASE HOLE COVER

Using a screwdriver, remove the switch base hole cover.

HINT:

Tap the screwdriver tip before use.

3. REMOVE ROOM TEMPERATURE SENSOR

(a) Disconnect the connector and aspirator hose.

(b) LHD models:

Remove the screw and sensor.

(c) RHD models:

Remove the sensor.

4. INSPECT ROOM TEMPERATURE SENSOR

(See [page DI-1775](#))

5. INSTALL ROOM TEMPERATURE SENSOR