

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Fuel lid opener system does not operate	1. Fuel lid opener switch circuit	05-2833
	2. Fuel lid opener motor circuit	05-2836
	3. Luggage room J/B ECU	05-2822
	4. Driver side J/B ECU	05-2822