



INSTALLATION

1. CHECK TORQUE CONVERTER INSTALLATION

Using calipers and a straight edge, measure from the installed surface of the torque converter to the front surface of the transmission housing.

Correct distance: More than 17.1 mm (0.673 in.)

If the distance is less than the standard, check for an improper installation.

2. INSTALL TRANSMISSION

Installation is in the reverse order of removal (See page AT-35).

HINT:

After installation, check and inspect items as follows.

- Adjust the shift lever position (See page DI-170).
- Check fluid level (See page DI-170).
- Do the road test (See page DI-170).