

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Driver side power shoulder belt anchor cannot be operate	1. Power source circuit (Driver door ECU)	05-1302
	2. Heigh adjustale anchor switch circuit (Driver side)	05-1307
	3. Shoulder belt anchor motor LH circuit	05-1311
	4. Driver door ECU	05-1290
	5. Driver side J/B ECU	05-1290
Passenger side power shoulder belt anchor cannot be operate	1. Power source circuit (Passenger door ECU)	05-1304
	2. Heigh adjustale anchor switch circuit (Passenger side)	05-1309
	3. Shoulder belt anchor motor RH circuit	05-1315
	4. Passenger door ECU	05-1290
	5. Passenger side J/B ECU	05-1290