


CIRCUIT OPENING RELAY INSPECTION

F10YD-01

1. REMOVE CIRCUIT OPENING RELAY (Marking: CIR OPN)

LOCATION: In the engine compartment relay box.




2. INSPECT CIRCUIT OPENING RELAY CONTINUITY

- (a) Using an ohmmeter, check that there is continuity between terminals 1 and 2.

If there is no continuity, replace the relay.

- (b) Check that there is no continuity between terminals 3 and 5.

If there is continuity, replace the relay.



3. INSPECT CIRCUIT OPENING RELAY OPERATION

- (a) Apply battery voltage across terminals 1 and 2.

- (b) Using an ohmmeter, check that there is continuity between terminals 3 and 5.

If there is no continuity, replace the relay.

4. REINSTALL CIRCUIT OPENING RELAY