



















AUTOMATIC TRANSMISSION

SST (Special Service Tools)

PP3F9-01

	09032-00100 Oil Pan Seal Cutter	
	09240-00020 Wire Gauge Set	
	09309-37010 Transmission Bearing Replacer	
	09350-30020 TOYOTA Automatic Transmission Tool Set	
	(09350-06120) No.2 Measure Terminal	
	(09350-07020) Oil Pump Puller	
	(09350-07030) No.1 Piston Spring Compressor	
	(09350-07040) No.2 Piston Spring Compressor	
	(09350-07050) No.3 Piston Spring Compressor	
	(09350-07060) No.1 Snap Ring Expander	
	(09350-07070) No.2 Snap Ring Expander	
	(09350-07080) Brake Reaction Sleeve Puller	

	(09350-07110) Oil Seal Replacer	
	(09351-32040) No.1 Piston Spring Compressor	
	09950-60010 Replacer Set	
	(09951-00350) Replacer 35	
	09950-70010 Handle Set	
	(09951-07100) Handle 100	