


ECM COMMUNICATION STOP MODE


MODE DESCRIPTION

Detection Item	Symptom	Trouble Area
ECM COMMUNICATION STOP MODE	<ul style="list-style-type: none"><li>• "Engine" and "ECT" are not displayed on the "Communication Bus Check" screen of the intelligent tester.</li><li>• Applies to "ECM COMMUNICATION STOP MODE" in the "DTC COMBINATION TABLE" (see page 05-3309).</li></ul>	<ul style="list-style-type: none"><li>• Power source or inside the ECM</li><li>• ECM sub bus line or connector</li></ul>

WIRING DIAGRAM




RHD:



INSPECTION PROCEDURE

1 CHECK CAN BUS LINE FOR DISCONNECTION(ECM SUB BUS LINE)



- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the ECM connector (E4).
- (c) Measure the resistance according to the value(s) in the table below.

Standard:


Tester connection	Condition	Specified value
E4-25 (CANH) - E4-24 (CANL)	Ignition Switch OFF	54 to 69 Ω

NG

REPAIR OR REPLACE ECM SUB BUS LINE OR CONNECTOR (CAN-H, CAN-L)

OK

2 CHECK WIRE HARNESS(+B1, +B, E1)



- (a) Disconnect the ECM connector (E7).
- (b) Measure the resistance according to the value(s) in the table below.
- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
E7-7 (E1) - Body ground	Always	Below 1 Ω
E4-5 (+B1) - Body ground	Ignition Switch ON	10 to 14 V
E4-6 (+B) - Body ground	Ignition Switch ON	10 to 14 V

NG

REPAIR OR REPLACE WIRE HARNESS OR CONNECTOR

OK

REPLACE ECM(SEE PAGE 10-21)