

DTC	B2621	COMMUNICATION INTERRUPTION
-----	-------	----------------------------

CIRCUIT DESCRIPTION

The multiplex tilt & telescopic ECU forms a network with the ECUs of other systems through the communication bus. Each ECU informs the other ECUs that it connects to the network with by outputting a specified signal (periodical signal) onto the communication bus on a regular schedule. The multiplex tilt & telescopic ECU detects the connection of each ECU based on the signal.

DTC No. (See Page)	Detection Item	Trouble Area
B2621	Periodical signal from the specified ECU has stopped.	<ul style="list-style-type: none"> • Multiplex communication system • Driver side J/B • Position control ECU & switch Assy (Driver seat ECU) • Turn signal switch Assy • Steering column Assy (Steering lock ECU) • Multiplex tilt & telescopic ECU

WIRING DIAGRAM

See page 05-3180, 05-3212.

INSPECTION PROCEDURE

1	READ VALUE ON INTELLIGENT TESTER II (MULTIPLEX TILT & TELESCOPIC ECU – DRIVER SIDE J/B)
---	---

- Connect the intelligent tester II to the DLC3.
- Turn the ignition switch to the ON position and turn the intelligent tester II on.
- Select "Receive from Body" from the DATA LIST.
- Check the signal communication state of the driver side J/B on the tester screen.

Item	Measurement Item/ Range (Display)	Normal Condition	Diagnostic Note
Receive from Body	Communication state of body ECU signal/OK or Interruption	OK: Communication is normal Interruption: Communication is interrupted	–

OK: "OK" is displayed.

NG

REPLACE DRIVER SIDE J/B

OK

2 READ VALUE ON INTELLIGENT TESTER II (MULTIPLEX TILT & TELESCOPIC ECU – DRIVER SEAT ECU)

- (a) Select "Receive from Seat ECU" from the DATA LIST.
 (b) Check the signal communication state of the driver seat ECU on the tester screen.

Item	Measurement Item/ Range (Display)	Normal Condition	Diagnostic Note
Receive from Seat ECU	Communication state of seat ECU signal/OK or Interruption	OK: Communication is normal Interruption: Communication is interrupted	–

OK: "OK" is displayed.

NG

REPLACE POSITION CONTROL ECU & SWITCH ASSY (DRIVER SEAT ECU) (SEE PAGE 72-3)

OK

3 READ VALUE ON INTELLIGENT TESTER II (MULTIPLEX TILT & TELESCOPIC ECU – TURN SIGNAL SWITCH ASSY)

- (a) Select "COMBI ECU INFO" from the DATA LIST.
 (b) Check the signal communication state of the turn signal switch assy on the tester screen.

Item	Measurement Item/ Range (Display)	Normal Condition	Diagnostic Note
Receive from Combi	Communication state of turn signal switch assy (combination switch) signal/OK or Interruption	OK: Communication is normal Interruption: Communication is interrupted	–

OK: "OK" is displayed.

NG

REPLACE TURN SIGNAL SWITCH ASSY (SEE PAGE 65-25)

OK

4 READ VALUE ON INTELLIGENT TESTER II (MULTIPLEX TILT & TELESCOPIC ECU – STEERING LOCK ECU)

- (a) Select "STRLOCK ECU INF" from the DATA LIST.
 (b) Check the signal communication state of the steering lock ECU on the tester screen.

Item	Measurement Item/ Range (Display)	Normal Condition	Diagnostic Note
Steering lock ECU	Communication state of steering lock ECU signal/OK or Interruption	OK: Communication is normal Interruption: Communication is interrupted	–

OK: "OK" is displayed.

NG

REPLACE STEERING COLUMN ASSY (STEERING LOCK ECU) (SEE PAGE 50-10)

OK

REPLACE MULTIPLEX TILT & TELESCOPIC ECU (SEE PAGE 50-26)