

PROBLEM SYMPTOMS TABLE

If there are no DTCs output but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

Symptoms	Suspect Areas	See page
ABS does not operate BA does not operate EBD does not operate	1. Check the DTC again and make sure that the normal code is output. 2. G power source circuit and ground circuit. 3. Speed sensor circuit 4. Check the ABS & TRC actuator with the Intelligent Tester II. (Check ABS & TRC actuator operation using the active test function.) If abnormal, check the hydraulic circuit for leakage. 5. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05-400 05-455 05-412 05-420 32-52
ABS does not operate efficiently BA does not operate efficiently EBD does not operate efficiently	1. Check the DTC again and make sure that the normal code is output. 2. Speed sensor circuit 3. Stop lamp switch circuit 4. Check the ABS & TRC actuator with the Intelligent Tester II. If abnormal, check the hydraulic circuit for leakage. 5. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05-400 05-412 05-420 05-460 32-52
ABS warning light abnormal	1. ABS warning light circuit 2. Skid control ECU	05-476 or 05-480 -
DTC of ABS check cannot be done	1. Check the DTC again and make sure that the normal code is output. 2. TC terminal circuit 3. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05-400 05-508
Sensor signal check cannot be done	1. TS terminal circuit 2. Skid control ECU	05-512 -
VSC and/or TRC does not operate	1. Check the DTC again and make sure that the normal code is output. 2. G power source circuit and ground circuit. 3. Check the hydraulic circuit for leakage. 4. Speed sensor circuit 5. Yaw rate/Deceleration sensor circuit 6. Steering sensor circuit 7. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.	05-400 05-455 - 05-412 05-420 05-441 05-448 05-444
SLIP indicator light abnormal	1. SLIP indicator light circuit 2. Skid control ECU	05-501 -

Symptoms	Suspect Areas	See page
TRC OFF indicator abnormal	<ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output. 2. TRC control switch circuit 3. TRC indicator circuit 4. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 	05-400 05-496
DTC of VSC check cannot be done	<ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output. 2. TC terminal circuit 3. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 	05-400 05-508
VSC warning light abnormal (Multi - Information Display)	<ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output. 2. VSC warning circuit 3. If the symptoms still occur even after the above circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 	05-400 05-482 or 05-486