

MIRROR MOTOR CIRCUIT

CIRCUIT DESCRIPTION


When the mirror motor circuit detects that the shift lever is:

- In the R position: motors move the driver side mirror 3 degrees downward and the passenger side mirror 3.5 degrees downward.
- In a position other than R: motors do not activate unless mirrors have been moved downward, in which case they return to their original position.


Mirror motors are built into the remote control mirrors.

WIRING DIAGRAM

Remote Control Mirror LH



Remote Control Mirror RH



*1: LHD
*2: RHD

INSPECTION PROCEDURE

1 PERFORM ACTIVE TEST USING INTELLIGENT TESTER

- (a) Connect the Intelligent Tester II to the DLC3.
 (b) Turn the Ignition switch ON and press the Intelligent Tester II main switch ON.
 (c) Select the item below in the ACTIVE TEST and then check that the remote control mirror operates.

Door ECU:

Item	Test Details
Mirr Up/Down	Mirror vertical operation UP/DOWN
Mirr Right/Left	Mirror horizontal operation RIGHT/LEFT

OK:

The motor operates normally.

NG

Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE
 (See page 05-2080)

2 INSPECT MIRROR MOTOR (See page 70-39)

NG

REPLACE REMOTE CONTROL MIRROR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE
 (See page 05-2080)