

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Sliding roof control system does not operate	5. Passenger side J/B • S/ROOF fuse • P-IG1 relay 6. Wire harness 7. Sliding roof drive gear assy 8. Overhead J/B	05-2959 05-2963
Sliding roof operates abnormally or stops halfway	1. Sliding roof drive gear assy 2. Sliding roof 3. Wire harness	 05-2966
Jam protection function does not operate (except Australia spec.)	1. Passenger side J/B • S/ROOF fuse • P-IG1 relay 2. Wire harness 3. Sliding roof drive gear assy	 05-2959