

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
All doors cannot be locked/unlocked simultaneously (power window regulator master switch assy)	1. Power source circuit 2. Power window regulator master switch assy 3. Door control switch circuit (built in power window regulator master switch) 4. Driver door ECU 5. Theft warning ECU	05-2551 05-2613 05-2613 05-2531 05-3076
All doors cannot be locked/unlocked simultaneously (door control switch)	1. Power source circuit 2. Door control switch assy 3. Door control switch circuit 4. Driver door ECU 5. Theft warning ECU	05-2551 05-2613 05-2613 05-2531 05-3076
All doors cannot be locked/unlocked simultaneously (driver door key cylinder)	1. Power source circuit 2. Front door lock assy LH 3. Driver door ECU 4. Theft warning ECU	05-2551 05-2613 05-2531 05-3076
Driver side door lock does not operate	1. Door lock motor circuit 2. Door lock position switch circuit 3. Power source circuit 4. Driver door ECU 5. Theft warning ECU	05-2572 05-2564 05-2551 05-2531 05-3076
Passenger side door lock does not operate	1. Door lock motor circuit 2. Door lock position switch circuit 3. Power source circuit 4. Passenger door ECU 5. Theft warning ECU	05-2553 05-2566 05-2553 05-2531 05-3076
Rear LH side door lock does not operate	1. Door lock motor circuit 2. Door lock position switch circuit 3. Power source circuit 4. Rear door ECU LH 5. Theft warning ECU	05-2576 05-2568 05-2556 05-2531 05-3076
Rear RH side door lock does not operate	1. Door lock motor circuit 2. Door lock position switch circuit 3. Power source circuit 4. Rear door ECU RH 5. Theft warning ECU	05-2578 05-2570 05-2560 05-2531 05-3076

Key lock-in prevention function does not work properly (manual operation and key-linked lock are active)	<ol style="list-style-type: none"> 1. Front door courtesy lamp switch circuit (Driver side) 2. Unlock warning switch circuit 3. Driver door ECU 4. Theft warning ECU 	05-2596 05-2991 05-2531 05-3076
w/ Double lock system: Double lock system does not operate properly	<ol style="list-style-type: none"> 1. Power source circuit on driver side door 2. Power source circuit on passenger side door 3. Power source circuit on rear LH side door 4. Power source circuit on rear RH side door 5. Double lock motor circuit on driver side door 6. Double lock motor circuit on passenger side door 7. Double lock motor circuit on rear LH side door 8. Double lock motor circuit on rear RH side door 9. Double lock position switch circuit on driver side door 10. Double lock position switch circuit on passenger side door 11. Double lock position switch circuit on rear LH side door 12. Double lock position switch circuit on rear RH side door 13. Driver door ECU 14. Passenger door ECU 15. Rear door ECU LH 16. Rear door ECU RH 17. Theft warning ECU 	05-2551 05-2553 05-2556 05-2560 05-2588 05-2590 05-2592 05-2594 05-2580 05-2582 05-2584 05-2586 05-2531 05-2531 05-2531 05-2531 05-3076