


CLEARANCE SONAR MAIN SWITCH CIRCUIT

CIRCUIT DESCRIPTION

Turning this switch on activates the clearance sonar system.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER

- Connect the intelligent tester to the DLC3.
- Turn the ignition switch to the ON position.
- Turn the intelligent tester on.
- Turn the clearance sonar main switch on.
- Select the item below in the DATA LIST, and read its value displayed on the intelligent tester to check the clearance sonar main switch.

CSONAR:


Condition	Item	Standard
Clearance Sonar Main Switch on	Main Switch	"ON" is displayed

OK

PROCEED TO NEXT CIRCUIT INSPECTION
SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-2229)

NG

2 INSPECT CLEARANCE WARNING ECU ASSY (CLSW TERMINAL)



- Disconnect the C17 connector from the clearance warning ECU Assy.
- Measure the voltage according to the value(s) in the table below.

Standard:


Tester connection	Condition	Specified condition
C17-3 (CLSW) - C17-7 (MGND)	<ul style="list-style-type: none"> Ignition switch on Clearance sonar main switch on 	10 to 14 V

OK

REPLACE CLEARANCE WARNING ECU ASSY
(SEE PAGE 67-30)

NG

3 CHECK HARNESS AND CONNECTOR(CLEARANCE WARNING ECU ASSY - BODY GROUND)



- (a) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
C17-7 (MGND) - Body ground	Always	Below 1 Ω


NG

REPAIR OR REPLACE HARNESS OR CONNECTOR (CLEARANCE WARNING ECU ASSY - BODY GROUND)

OK

4 INSPECT OUTER MIRROR SWITCH ASSY

Outer Mirror Switch Assy Connector:



- (a) Disconnect the O5 connector from the clearance sonar main switch.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection (Symbols)	Condition	Specified condition
O5-3 - O5-4	Clearance sonar main switch off	10 k Ω or higher
O5-3 - O5-4	Clearance sonar main switch on	Below 1 Ω

NG

REPLACE OUTER MIRROR SWITCH ASSY

OK

REPAIR OR REPLACE HARNESS OR CONNECTOR (CLEARANCE WARNING ECU ASSY - BATTERY)