

DATA LIST/ACTIVE TEST

1. DATA LIST

- (a) Connect the intelligent tester II to the DLC3.
- (b) Turn the ignition switch to the ON position and turn the intelligent tester II on.
- (c) Operate the intelligent tester II according to the steps on the display and select "DATA LIST".

Item	Measurement Item/ Range (Display)	Normal Condition	Diagnostic Note
Push SW	PUSH SW/OFF or ON	OFF: Push switch is turned OFF ON: Push switch is turned ON	–
Key SW	KEY SW/OFF or ON	OFF: Key switch is turned OFF ON: Key switch is turned ON	–
IG SW	IG SW/OFF or ON	OFF: IG switch is turned OFF ON: IG switch is turned ON	–
Lock Position Sensor	Lock position sensor/OFF or ON	OFF: Steering lock shaft is un-locked ON: Steering lock shaft is locked	–
Unlock Positioin Sensor	Unlock position sensor/OFF or ON	OFF: Steering lock shaft is locked ON: Steering lock shaft is un-locked	–
Unlock Sensor	Unlock sensor/LOCK or UNLOCK	LOCK: Interlock cable position is locked UNLOCK: Interlock cable position is unlocked	–
Steering Lock	Steering lock/SET or UNSET	SET: Steering lock is activated UNSET: Steering lock is not acti- vated	–
Immobiliser	IMMOBILISER/SET or UNSET	SET: Immobilizer is activated UNSET: Immobilizer is not acti- vated	–
Check(Security)	CHECK (SECURITY)/ABNOML or NORMAL	ABNORMAL: Interior verification is abnormal NORMAL: Interior verification is normal	–
Security Com ID	Security communication ID/NG or OK	NG: Security ECU communication ID verification is abnormal OK: Security ECU communication ID verification is normal	–
Security B Code	Security B code/NO REGD or REGD	NO REGD: Security B code is not registered (for security ECU com- munication) REGD: Security B code is regis- tered (for security ECU commu- nication)	–
P2SW	P2SW/NOT P or P	NOT P: Shift lever is not in P posi- tion P: Shift lever is in P position	–

2. ACTIVE TEST

- (a) Connect the intelligent tester II to the DLC3.
- (b) Turn the ignition switch to the ON position and turn the intelligent tester II on.
- (c) Following the display on the intelligent tester II, perform the "ACTIVE TEST".

Item	Vehicle Condition/Test Details	Diagnostic Note
Security Indicator	Security indicator/OFF or ON	–
Meter Chime	Meter chime/OFF or ON	–
Meter Buzzer	Meter buzzer/OFF or ON	–
Not P–position Warning	Not P–position warning/OFF or ON	Confirm that all doors are closed.
Break Cable Warning	Break cable warning/OFF or ON	Confirm that all doors are closed.
Unmatch Key Warning	Unmatch key warning/OFF or ON	Confirm that all doors are closed.
Stuck Steering Warning	Stuck steering warning/OFF or ON	–
Meter Chime2	Meter chime continuously/OFF or ON	–