


## REASSEMBLY

### HINT:

Before reassembly, apply MP grease to the parts indicated by arrows (See page AT-1)




### 1. INSTALL CLIP, CONNECTING ROD SWIVEL, LOWER CONTROL SHAFT BUSH, LOWER CONTROL SHAFT PIECE AND PLATE WASHER TO CONTROL LEVER

- (a) Install the 2 plate washers, lower control shaft piece, lower control shaft bush and connecting rod swivel to the control lever.
- (b) Using pliers, install the clip.


### 2. INSTALL CONTROL LEVER, SHIFT LEVER BOOT, SPACER AND CONTROL SHAFT

- (a) Install the shift lever boot to the shift lever.
- (b) Connect the shift lever boot to the shift lever plate.
- (c) Using a wire brush, remove the adhesive adhered to the threads of control shaft.




- (d) Install the control shaft and 2 spacers.
- (e) Install the washer and torque a new nut.

**Torque: 19 N·m (194 kgf·cm, 14 ft·lbf)**



### 3. INSTALL SHIFT LEVER SUB-ASSEMBLY

- (a) Install the pin and shift lever sub-assembly.
- (b) Install the shift lever nut.




#### 4. INSTALL SHIFT LOCK PLATE STOPPER

(a) Install the shift lever torsion spring.

HINT:


Hook the spring on to the shift lever plate as shown in the illustration.




(b) Install the shift lock plate stopper.

HINT:

Hook the spring on to the shift lock plate stopper as shown in the illustration.




(c) Install a new spring damper to the shift lock plate stopper by knocking them lightly via the 10 – mm seated nut.



#### 5. INSTALL SHIFT LOCK CONTROL COMPUTER


Install the shift lock control computer with the 2 screws.

**Torque: 2.0 N·m (20, 17 in.·lbf)**




HINT:

Connect the solenoid of the shift lock control computer and the shift lock plate stopper as shown in the illustration.




## 6. INSTALL COMPRESSION SPRING AND SHIFT LEVER DETENT PIN TO SHIFT LEVER SUB-ASSEMBLY




## 7. INSTALL SHIFT LEVER GUIDE HOUSING


- (a) Install the shift lever torsion spring and a new spring holder to the shift lever guide housing.



- (b) Install the No. 1 shift lock switch plate to the shift lever guide housing.
- (c) Connect the position indicator housing plate and shift lever guide housing sub-assembly.
- (d) Install the shift lever guide housing to the shift lever plate.



- (e) Install the 2 nuts and bolts.  
**Torque: 3.0 N·m (29, 25 in.-lbf)**



## 8. INSTALL SHIFT LOCK RELEASE LINK AND SPRING ASSEMBLY

## 9. ASSEMBLE INDICATOR LAMP WIRE SUB-ASSEMBLY

- (a) Install the terminals of the indicator lamp wire sub-assembly to the connector.
- (b) Install the bulb to the indicator lamp wire sub-assembly.


## 10. INSTALL SLIDE COVER

## 11. INSTALL INDICATOR LAMP WIRE SUB-ASSEMBLY


Install the indicator lamp wire sub-assembly to the position indicator lens.

**12. INSTALL POSITION INDICATOR HOUSING**

- (a) Install the shift lock release button to the position indicator housing.
- (b) Install the 4 spring holders to the position indicator housing.




- (c) Install the position indicator lens to the position indicator housing.



- (d) Install the position indicator housing to the shift lever plate.

**HINT:**

Fit the 4 clips of the position indicator housing in the shift lever plate securely.



- (e) Connect the indicator lamp wire sub-assembly to the shift lever plate.

**13. INSTALL SHIFT LEVER KNOB AND SHIFT LEVER KNOB COVER**