



INSPECTION

INSPECT BALL JOINT FOR ROTATION CONDITION

- Flip the ball joint stud back and forth 5 times before installing the nut.
- Using a torque wrench, turn the nut continuously one turn every 2–4 seconds and take the torque reading on the 5th turn.

Torque (turning):

1.0 – 3.4 N·m (10 – 35 kgf·cm, 9 – 30 in.·lbf)