



SMOG VENTILATION SENSOR INSPECTION

AC3D2-01

1. REMOVE SMOG VENTILATION SENSOR

- (a) Disconnect the connector.
- (b) Remove the bolt and smog ventilation sensor.

2. INSPECT SMOG VENTILATION SENSOR CIRCUIT (See [page DI-1790](#), [DI-1827](#))

3. INSTALL SMOG VENTILATION SENSOR