


## INSTALLATION

### NOTICE:

- **Never use SRS parts from another vehicle. When replacing parts, replace them with new ones.**
- **Never reuse the side and curtain shield airbag sensor assembly involved in a collision when the airbag has deployed.**
- **Never repair a sensor in order to reuse it.**

### HINT:

For step 3 to 5, refer to [page RS-48](#).



### 1. INSTALL SIDE AND CURTAIN SHIELD AIRBAG SENSOR

- (a) Install the side and curtain shield airbag assembly with 3 bolts.

**Torque: 20 N·m (205 kgf·cm, 15 ft·lbf)**

- (b) Connect the connector.

### NOTICE:

- **Connection of the connector is done after the sensor assembly has been installed.**
- **Make sure the sensor assembly is installed with the specified torque.**
- **If the sensor assembly has been dropped, or there are cracks, dents or other defects in the case, bracket or connector, replace the sensor assembly with a new one.**
- **When installing the sensor assembly, take care that the SRS wiring does not interfere with other parts and is not pinched between other parts.**
- **After installation, shake the sensor assembly to check that there is no looseness.**

### 2. INSTALL RETRACTOR OF FRONT SEAT OUTER BELT

**Torque:**

**Upper bolt: 7.5 N·m (75 kgf·cm, 67 in·lbf)**

**Lower bolt: 42 N·m (430 kgf·cm, 31 ft·lbf)**

3. **INSTALL CENTER PILLAR LOWER GARNISH**
4. **INSTALL FRONT DOOR SCUFF PLATE**
5. **INSTALL REAR DOOR SCUFF PLATE**