

## SHOULDER BELT ANCHOR MOTOR CIRCUIT ON PASSENGER SIDE DOOR

### CIRCUIT DESCRIPTION


The passenger side J/B ECU receives the seat belt anchor switch signal from the passenger door ECU to operate the seat belt anchor motor.

### WIRING DIAGRAM

S27\*1, S26\*2

Shoulder Belt Anchor Motor  
(Passenger Side)

Passenger Side J/B ECU




\*1: LHD

\*2: RHD

## INSPECTION PROCEDURE

## 1 INSPECT SHOULDER BELT ANCHOR MOTOR (PASSENGER SIDE) (MOTOR)



- (a) Disconnect the motor connector.  
 (b) Apply battery voltage to the shoulder belt anchor motor.

OK:


Measurement Condition	Specified Condition
Battery positive (+) → Terminal 4 Battery negative (-) → Terminal 3	Slider moves upward
Battery positive (+) → Terminal 3 Battery negative (-) → Terminal 4	Slider moves downward

NG

REPLACE SHOULDER BELT ANCHOR MOTOR (PASSENGER SIDE)

OK

## 2 CHECK WIRE HARNESS (SHOULDER BELT ANCHOR MOTOR (PASSENGER SIDE) - PASSENGER SIDE J/B ECU)



- (a) Disconnect the P5 ECU connector.  
 (b) Disconnect the S26/S27 motor connector.  
 (c) Measure the resistance between the wire harness side connector.

Standard:  
(LHD)

Tester Connection	Specified Condition
P5-3 (PBM+) - S27-4 (UP)	Below 1 Ω
P5-4 (PBM-) - S27-3 (DOWN)	Below 1 Ω

(RHD)

Tester Connection	Specified Condition
P5-3 (PBM+) - S26-4 (UP)	Below 1 Ω
P5-2 (PBM-) - S26-3 (DOWN)	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-1289)