


VIBRATOR CIRCUIT (RH)

CIRCUIT DESCRIPTION


The rear RH seat ECU sends a vibration seat function signal to the vibrator through the vibration seat ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT VIBRATOR RH



- (a) Remove the vibrator RH.
- (b) Measure the resistance of the vibrator.

Standard:

Tester Connection	Specified Condition
1*1 - 2	1.8 ± 0.3 Ω
1 or 2*2 - Body ground	5 MΩ or more at DC 500 VM
3 - Body ground	0 Ω


HINT:

- *1: Connect terminal 1 to the tester's positive (+) terminal.
- *2: Terminals 1 and 2 should be connected together.

NG REPLACE VIBRATOR RH

OK

2 CHECK WIRE HARNESS (VIBRATION SEAT ECU RH - VIBRATOR RH)



- (a) Disconnect the V11 ECU and V13 vibrator connectors.
- (b) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
V11-12 (VIBE) - V13-3 (C3)	Below 1 Ω
V11-1 (VIB+) - V13-1 (C2)	Below 1 Ω
V11-6 (VIB-) - V13-2 (C1)	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE
(See [page 05-2340](#))