

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Horn does not sound.	1. HORN fuse	77-4
	2. High pitched horn	77-4
	3. Low pitched horn	77-4
	4. Horn button switch	-
	5. Wire harness	-

