


DTC	C0200/31	RIGHT FRONT SPEED SENSOR
------------	-----------------	---------------------------------

DTC	C0205/32	LEFT FRONT SPEED SENSOR
------------	-----------------	--------------------------------

CIRCUIT DESCRIPTION



The speed sensor detects wheel speed and sends the appropriate signals to the ECU. These signals are used to control the ABS control system. The front and rear rotors have 48 serrations each.


When the rotors rotate, the magnetic field emitted by the permanent magnet in the speed sensor generates an AC voltage. Since the frequency of this AC voltage changes in direct proportion to the speed of the rotor, the frequency is used by the ECU to detect the speed of each wheel.

DTC No.	DTC Detecting Condition	Trouble Area
C0200/31 C0205/32	(1) All of following conditions continue for at least 1 second. • Vehicle speed is more than 10 km/h (6 mph). • Open or short in vehicle speed sensor signal circuit. (2) Momentary interruption of the sensor signal of faulty wheel has occurred 7 times or more. (3) Sensor signal circuit is open for 0.5 seconds.	• Right front and left front speed sensor • Each speed sensor circuit • Sensor rotor • Sensor installation

HINT:

- DTC C0200/31 is for the right front speed sensor.
- DTC C0205/32 is for the left front speed sensor.

WIRING DIAGRAM



INSPECTION PROCEDURE**1 CHECK HARNESS AND CONNECTOR (MOMENTARY INTERRUPTION)**

- (a) Using the intelligent tester II, check for any momentary interruption in the wire harness and connector corresponding to a DTC (see page 05-385).

Item	Measurement Item / Range (Display)	Normal Condition
FR Speed Open	FR speed sensor open detection / OPEN or NORMAL	OPEN : Momentary interruption
FL Speed Open	FL speed sensor open detection / OPEN or NORMAL	OPEN : Momentary interruption

OK:

There are no momentary interruptions.

HINT:

Perform the above inspection before removing the sensor and connector.

NG

Go to step 5

OK

2 READ VALUE OF INTELLIGENT TESTER II (FRONT SPEED SENSOR)

- (a) Connect the intelligent tester II to the DLC3.
 (b) Start the engine.
 (c) Select the DATA LIST mode on the intelligent tester II.

Item	Measurement Item / Range (Display)	Normal Condition
FR Wheel Speed	Wheel speed sensor (FR) reading / min.: 0 km/h (0 MPH, max.: 326 km/h (202 MPH)	Actual wheel speed
FL Wheel Speed	Wheel speed sensor (FL) reading / min.: 0 km/h (0 MPH, max.: 326 km/h (202 MPH)	Actual wheel speed

- (d) Check that there is no difference between the speed value output from the speed sensor displayed on the intelligent tester II and the speed value displayed on the speedometer when driving the vehicle.

OK:

There is almost no difference from the displayed speed value.

HINT:


There is tolerance of $\pm 10\%$ in the speedometer indication.

NG

Go to step 4

OK

3 INSPECT SPEED SENSOR AND SENSOR ROTOR ERRATIONS



INSPECTION USING OSCILLOSCOPE

- Connect the oscilloscope to terminal FR+ - FR- or FL+ - FL- of the skid control ECU.
- Drive the vehicle at approximately 30 km/h (19 mph), and check the signal waveform.

OK:

A waveform as shown in a figure should be output.

HINT:

- As the vehicle speed (wheel revolution speed) increases, a cycle of the waveform narrows and the fluctuation in the output voltage becomes greater.
- When noise is identified in the waveform on the oscilloscope, error signals are generated due to the speed sensor rotor scratches, looseness or foreign matter attached to it.

NG

Go to step 7


OK

REPLACE ABS & TRACTION ACTUATOR ASSY (SEE PAGE 32-53)

NOTICE:

When replacing the ABS & TRACTION actuator assy, perform zero point calibration (see page 05-387).

4 INSPECT FRONT SPEED SENSOR



- (a) Make sure that there is no looseness at the connectors' locking part and connecting part of connector.
- (b) Disconnect the speed sensor connector.
- (c) Measure the resistance according to the value(s) in the table below.

Standard:

LH:

Tester Connection	Specified Condition
A8-2 (FL+) - A8-1 (FL-)	0.6 to 2.5 kΩ

RH:

Tester Connection	Specified Condition
A7-2 (FR+) - A7-1 (FR-)	0.6 to 2.5 kΩ

- (d) Measure the resistance according to the value(s) in the table below.


Standard:

LH:

Tester Connection	Specified Condition
A8-2 (FL+) - Body ground	1 MΩ or higher
A8-1 (FL-) - Body ground	1 MΩ or higher

RH:

Tester Connection	Specified Condition
A7-2 (FR+) - Body ground	1 MΩ or higher
A7-1 (FR-) - Body ground	1 MΩ or higher

**FRONT SPEED SENSOR SUB-WIRE HARNESS**

- Remove the front tender liner.
- Make sure that the speed sensor connector and the wire harness side connector are securely connected.
- Disconnect the speed sensor connector inside the vehicle.
- Measure the resistance according to the value(s) in the table below.

Standard:**LH:**

Tester Connection	Specified Condition
(Connector A-1) - (Connector B-1)	Below 1 Ω
(Connector A-2) - (Connector B-2)	Below 1 Ω

RH:

Tester Connection	Specified Condition
(Connector A-1) - (Connector B-1)	Below 1 Ω
(Connector A-2) - (Connector B-2)	Below 1 Ω

- Measure the resistance according to the value(s) in the table below.

Standard:**LH:**

Tester Connection	Specified Condition
(Connector A-1) - (Connector A-2)	1 MΩ or higher

RH:

Tester Connection	Specified Condition
(Connector A-1) - (Connector A-2)	1 MΩ or higher

- Measure the resistance according to the value(s) in the table below.

Standard:**LH:**

Tester Connection	Specified Condition
(Connector A-1) - Body Ground	1 MΩ or higher
(Connector A-2) - Body Ground	1 MΩ or higher

RH:

Tester Connection	Specified Condition
(Connector A-1) - Body Ground	1 MΩ or higher
(Connector A-2) - Body Ground	1 MΩ or higher

NOTICE:


Check the speed sensor signal after replacement (see page 05-389).

NG

REPLACE FRONT SPEED SENSOR
(SEE PAGE 32-61)

OK

5 CHECK HARNESS AND CONNECTOR(FRONT SPEED SENSOR – SKID CONTROL ECU)



- Disconnect the skid control ECU connector and the front speed sensor connector.
- Measure the resistance according to the value(s) in the table below.

Standard:

LH:

Tester Connection	Specified Condition
S48-18 (FL+) – A8-2 (FL+)	Below 1 Ω
S48-4 (FL-) – A8-1 (FL-)	Below 1 Ω

RH:

Tester Connection	Specified Condition
S48-3 (FR+) – A7-2 (FR+)	Below 1 Ω
S48-17 (FR-) – A7-1 (FR-)	Below 1 Ω

- Measure the resistance according to the value(s) in the table below.

Standard:

LH:

Tester Connection	Specified Condition
S48-18 (FL+) – Body ground	1 M Ω or higher
S48-4 (FL-) – Body ground	1 M Ω or higher

RH:


Tester Connection	Specified Condition
S48-3 (FR+) – Body ground	1 M Ω or higher
S48-17 (FR-) – Body ground	1 M Ω or higher

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

6 INSPECT SPEED SENSOR AND SENSOR ROTOR SERRATIONS



INSPECTION USING OSCILLOSCOPE

- Connect the oscilloscope to terminal FR+ -FR- or FL+ -FL- of the skid control ECU.
- Drive the vehicle at approximately 30 km/h (19 mph), and check the signal waveform.

OK:

A waveform as shown in a figure should be output.

HINT:

- As the vehicle speed (Wheel revolution speed) increases, a cycle of the waveform narrows and the fluctuation in the output voltage becomes greater.
- When noise is identified in the waveform on the oscilloscope, error signals are generated due to the speed sensor rotor scratches, looseness or foreign matter attached to it.

NG → **Go to step 7**


OK

REPLACE ABS & TRACTION ACTUATOR ASSY (SEE PAGE 32-53)

NOTICE:

When replacing the ABS & TRACTION actuator assy, perform zero point calibration (see page 05-387).

7 INSPECT FRONT SPEED SENSOR INSTALLATION



- Check the speed sensor installation.

OK:

There is no clearance between the sensor and the front steering knuckle.

NOTICE:

Check the speed sensor signal after the replacement (see page 05-389).

NG → **REPLACE FRONT SPEED SENSOR**

OK

REPLACE ABS & TRACTION ACTUATOR ASSY (SEE PAGE 32-53)

NOTICE:

When replacing the ABS & TRACTION actuator assy, perform zero point calibration (see page 05-387).