

INSPECTION

1. INSPECT AIR INLET SERVOMOTOR CIRCUIT ([See page DI-1821](#))
2. INSPECT AIR INLET DAMPER POSITION SENSOR CIRCUIT ([See page DI-1808](#))