

## B78603

## INSPECTION PROCEDURE

## 1 PERFORM ACTIVE TEST USING INTELLIGENT TESTER

- (a) Select the ACTIVE TEST, use the intelligent tester to generate a control command, and then check that the double lock operates.

**Multiplex network body ECU (Driver door ECU):**

Item	Test Details	Diagnostic Note
Double Lock Unset	Double Lock Unset OFF/UNSET	This test is available only for vehicles equipped with double lock system

**OK: Double lock is UNSET.**


NG

Go to step 2

OK

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOM TABLE**  
(See page 05-2529)

## 2 CHECK DRIVER DOOR LOCK ASSY (DOUBLE LOCK MOTOR)



- (a) Check operation of the double lock motor.

- (1) Apply battery voltage and set the door lock motor to LOCK.
- (2) Apply battery voltage and inspect operation of the double lock motor.

**OK:**

Measurement Condition	Specified Condition
Battery positive (+) → Terminal 6 Battery negative (-) → Terminal 5	Double Lock System is Set
Battery positive (+) → Terminal 5 Battery negative (-) → Terminal 6	Double Lock System is Unset

NG

REPLACE DRIVER DOOR LOCK ASSY

OK

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE**  
(See page 05-2529)