

<b>DTC</b>	<b>B1263</b>	<b>Luggage Room Junction Block ECU communication stop</b>
------------	--------------	---

## CIRCUIT DESCRIPTION

This DTC is output when communication stops between the luggage room J/B ECU and the gateway ECU.

DTC No.	DTC Detecting Condition	Trouble Area
B1263	No communication from luggage room J/B ECU for more than 10 seconds.	<ul style="list-style-type: none"><li>• Luggage room J/B ECU</li><li>• Wire harness</li></ul>

## WIRING DIAGRAM

See [page DI-1533](#).

## INSPECTION PROCEDURE

<b>1</b>	<b>Check luggage room J/B ECU.</b>
----------	------------------------------------

### CHECK:

Check that the operation of luggage compartment door closer system is normal.

### HINT:

With this inspection, whether or not the luggage room J/B ECU functions normally can be diagnosed.

NG

Replace **luggage room J/B ECU** ([See page IN-35](#)).

OK

## 2 Check wire harness.


### PREPARATION:

Pull out the ECU connectors mentioned below.

Wire harness side connector of ECU	Terminal
Luggage room J/B ECU - Combination switch	MPX+ (L13-2) - MPX2 (C14-10)
Luggage room J/B ECU - Gateway ECU	MPX- (L13-13) - MPL1 (G1-6)

### CHECK:

Check continuity of the wire harness between the connectors.



### OK:

**There is a continuity between the connectors.**

HINT:

If there is OPEN in any wire harness, please repair it.

NG

**Repair or replace wire harness.**

OK

**Replace Luggage room J/B ECU (See page IN-35).**