

<b>DTC</b>	<b>B1615</b>	<b>FRONT AIRBAG SENSOR (LH) MALFUNCTION</b>
------------	--------------	---

## CIRCUIT DESCRIPTION


The front airbag sensor LH consists of the diagnostic circuit, the frontal deceleration sensor, etc.

If the airbag sensor assy center receives signals from the frontal deceleration sensor, it determines whether or not the SRS should be activated.

DTC B1615 is recorded when a malfunction is detected in the front airbag sensor LH circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1615	<ul style="list-style-type: none"> <li>When the airbag sensor assy center receives an open signal in the front airbag sensor LH circuit for 2 seconds.</li> <li>Airbag sensor front LH malfunction</li> <li>Airbag sensor assy center malfunction</li> </ul>	<ul style="list-style-type: none"> <li>Instrument panel wire</li> <li>Engine room main wire</li> <li>Airbag sensor front LH</li> <li>Airbag sensor assy center</li> </ul>

## WIRING DIAGRAM




## INSPECTION PROCEDURE

### CAUTION:

Be sure to perform the following procedures before troubleshooting to avoid unexpected airbag deployment.

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Disconnect the connectors from the airbag sensor Assy Center.
- (d) Disconnect the connectors from the horn button Assy.
- (e) Disconnect the connector from the front passenger airbag Assy.
- (f) Disconnect the connector from the instrument panel airbag Assy lower No. 1.
- (g) Disconnect the connector from the instrument panel airbag Assy lower No. 2.
- (h) Disconnect the connector from the front seat airbag Assy LH.
- (i) Disconnect the connector from the front seat airbag Assy RH.
- (j) Disconnect the connector from the curtain shield airbag Assy LH.
- (k) Disconnect the connector from the curtain shield airbag Assy RH.
- (l) Disconnect the connector from the front seat outer belt Assy LH.
- (m) Disconnect the connector from the front seat outer belt Assy RH.
- (n) Disconnect the connectors from the rear seat 3-point type outer belt Assy.

### 1 CHECK DTC



- (a) Connect the connectors to the airbag sensor Assy Center.
- (b) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (c) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (d) Clear the DTCs stored in memory (see page 05-959).
- (e) Turn the ignition switch to the LOCK position.
- (f) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (g) Check the DTCs (see page 05-959).

**OK:**

**DTC B1615 is not output.**

**HINT:**

Codes other than code B1615 may be output at this time, but they are not related to this check.

**NG**

**Go to step 2**

**OK**

**USE SIMULATION METHOD TO CHECK (SEE PAGE 05-954)**

2 CHECK CONNECTION OF CONNECTORS

- (a) Turn the ignition switch to the LOCK position.
- (b) Disconnect the negative (-) terminal cable from the battery, and wait for at least 90 seconds.
- (c) Check that the connectors are properly connected to the airbag sensor assy center and the airbag sensor front LH.


OK:  
The connectors are connected.

NG

CONNECT CONNECTORS, THEN GO TO STEP 1

OK

3 CHECK FRONT AIRBAG SENSOR (LH) CIRCUIT (OPEN)



- (a) Disconnect the connectors from the airbag sensor assy center and the airbag sensor front LH.
- (b) Using a service wire, connect A10-2 (+SL) and A10-1 (-SL) of connector "E".

**NOTICE:**  
Do not forcibly insert a service wire into the terminals of the connector when connecting.

- (c) Measure the resistance according to the value(s) in the table below.

Standard:


Tester connection	Condition	Specified condition
A27-30 (+SL) - A27-28 (-SL)	Always	Below 1 $\Omega$

NG

Go to step 5

OK

4 CHECK AIR BAG SENSOR FRONT LH



- (a) Connect the connectors to the airbag sensor assy center.
- (b) Interchange the airbag sensor front RH with LH and connect the connectors to them.
- (c) Connect the negative (-) terminal cable to the battery, and wait for at least 2 seconds.
- (d) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (e) Clear the DTCs stored in memory (see page 05-959).
- (f) Turn the ignition switch to the LOCK position.
- (g) Turn the ignition switch to the ON position, and wait for at least 60 seconds.
- (h) Check the DTCs (see page 05-959).

Result:

DTC B1615 is output.	A
DTC B1610 is output.	B
DTC B1610 or B1615 are not output.	C

A

REPLACE AIR BAG SENSOR ASSY CENTER  
(SEE PAGE 60-74)

B

REPLACE AIR BAG SENSOR FRONT LH  
(SEE PAGE 60-77)

C

USE SIMULATION METHOD TO CHECK (SEE PAGE 05-954)

Engine Room Main Wire

Instrument Panel Wire

Airbag Sensor Front LH

Airbag Sensor Front RH

Service Wire

A10

IB1 (\*1)

IC1 (\*2)

-SL

+SL

1 2

\*1: LHD

\*2: RHD

H44433 H44045

H44443

- Standard:**

Tester connection	Condition	Specified condition
IB1-1 (+SL) – IB1-2 (–SL)	Always	Below 1 Ω

Tester connection	Condition	Specified condition
IC1-1 (+SL) - IC1-2 (-SL)	Always	Below 1 $\Omega$

## REPAIR OR REPLACE ENGINE ROOM MAIN WIRE

## REPAIR OR REPLACE INSTRUMENT PANEL WIRE