

ENGINE


ON-VEHICLE INSPECTION

9902I-01

HINT:

Inspect these items when the engine is cold.

1. **REPLACE TIMING BELT** (See page 14-71)
2. **INSPECT DRIVE BELT** (See page 14-6)
3. **REPLACE SPARK PLUGS** (See page 18-4)
4. **INSPECT AIR FILTER**
 - (a) Remove the air filter.
 - (b) Visually check that the air filter is not excessively damaged or oily.
 - (c) Reinstall the air filter.
5. **REPLACE AIR FILTER**
 - (a) Replace the air filter with a new one.
6. **REPLACE ENGINE OIL AND OIL FILTER** (See page 17-3)



7. INSPECT COOLING, HEATER SYSTEM HOSES AND CONNECTIONS

(a) Check the relating parts for coolant leakage and damage.

• Radiator	• Water pump
• Radiator reservoir	• Cylinder block & Cylinder head
• Drain plugs	• Heater
• Water inlet	• Throttle body
• Water outlet	• Oil cooler

- (b) Check the hoses cracks or deterioration.
- (c) Check the clamps for looseness.
- (d) The coolant level at radiator reservoir should be between "LOW" and "FULL" lines.

8. **REPLACE ENGINE COOLANT** (See page 16-8)
9. **INSPECT GASKET IN FUEL TANK CAP** (See page 12-4)
10. **INSPECT FUEL LINES AND CONNECTIONS AND FUEL TANK VAPOR VENT SYSTEM HOSES AND FUEL TANK BANDS**
 - (a) Visually check the fuel lines for cracks, leakage, loose connections, deformation or tank band looseness.
11. **INSPECT EXHAUST PIPES AND MOUNTINGS**
 - (a) Visually check the pipes, hangers and connections for severe corrosion, leaks or damage.
12. **INSPECT VALVE CLEARANCE** (See page 14-7)