


## INSPECTION



## 1. Driver's side:

**INSPECT TRACTION CONTROL SWITCH (CLIMATE CONTROL SWITCH FRONT)**

- (a) Measure the resistance between the terminals when the switch is operated.

**Standard:**

Tester Connection	Condition	Specified Condition
1 (LV5) - 12 (LVS)	Switch ON (LH) Max.COOL to Max.WARM	Below 1 to 5 kΩ

**HINT:**


As the dial is being turned, the resistance changes gradually.  
If the result is not as specified, replace the seat heater switch.

- (b) Check that the seat heater switch indicator illuminates.

**OK:**

Measurement Condition	Condition	Specified Condition
Battery positive (+) → Terminal 3 (LIND) Battery negative (-) → Terminal 6 (E)	Constant	Illuminates
Battery positive (+) → Terminal 20 (ILL+) Battery negative (-) → Terminal 5 (ILL-)	Constant	Illuminates

If the result is not as specified, replace the switch or bulb.



## 2. Passenger's side:

**INSPECT TRACTION CONTROL SWITCH (CLIMATE CONTROL SWITCH FRONT)**

- (a) Measure the resistance between the terminals when the switch is operated.

**Standard:**

Tester Connection	Condition	Specified Condition
15 (RV5) - 16 (RVS)	Switch ON (RH) Max.COOL to Max.WARM	Below 1 to 5 kΩ

**HINT:**


As the dial is being turned, the resistance changes gradually.  
If the result is not as specified, replace the seat heater switch.

- (b) Check that the seat heater switch indicator illuminates.

**OK:**

Measurement Condition	Condition	Specified Condition
Battery positive (+) → Terminal 2 (RIND) Battery negative (-) → Terminal 6 (E)	Constant	Illuminates
Battery positive (+) → Terminal 20 (ILL+) Battery negative (-) → Terminal 5 (ILL-)	Constant	Illuminates

If the result is not as specified, replace the switch or bulb.



### 3. INSPECT SEAT CLIMATE CONTROLLER LH (FRONT SEAT CUSHION)

- (a) Measure the resistance between the terminals.

**Standard:**

Tester Connection	Condition	Specified Condition
3 (TDC+) – 6 (TDC-)	Constant	Below 1 $\Omega$

If the result is not as specified, replace the controller.

- (b) Measure the thermistor resistance between the terminals.


**Standard:**

Tester Connection	Condition	Specified Condition
1 (TCS) – 2 (TC5)	Controller temperature 10°C (50°F)	3.6 to 3.8 k $\Omega$
1 (TCS) – 2 (TC5)	Controller temperature 25°C (77°F)	1.9 to 2.1 k $\Omega$
1 (TCS) – 2 (TC5)	Controller temperature 30°C (86°F)	1.6 to 1.7 k $\Omega$

**HINT:**

As the temperature increases, the resistance decreases.

If the result is not as specified, replace the controller.



### 4. INSPECT SEAT CLIMATE CONTROLLER RH (FRONT SEAT CUSHION)

- (a) Measure the resistance between the terminals.

**Standard:**

Tester Connection	Condition	Specified Condition
3 (TDC+) – 6 (TDC-)	Constant	Below 1 $\Omega$

If the result is not as specified, replace the controller.

- (b) Measure the thermistor resistance between the terminals.


**Standard:**

Tester Connection	Condition	Specified Condition
1 (TCS) – 2 (TC5)	Controller temperature 10°C (50°F)	3.6 to 3.8 k $\Omega$
1 (TCS) – 2 (TC5)	Controller temperature 25°C (77°F)	1.9 to 2.1 k $\Omega$
1 (TCS) – 2 (TC5)	Controller temperature 30°C (86°F)	1.6 to 1.7 k $\Omega$

**HINT:**

As the temperature increases, the resistance decreases.

If the result is not as specified, replace the controller.



### 5. INSPECT SEAT CLIMATE CONTROLLER LH (FRONT SEATBACK)

- (a) Measure the resistance between the terminals.

**Standard:**

Tester Connection	Condition	Specified Condition
4 (TDB-) – 5 (TDB+)	Constant	Below 1 $\Omega$

If the result is not as specified, replace the controller.


- (b) Measure the thermistor resistance between the terminals.

**Standard:**

Tester Connection	Condition	Specified Condition
2 (TBS) – 3 (TB5)	Controller temperature 10°C (50°F)	3.6 to 3.8 kΩ
2 (TBS) – 3 (TB5)	Controller temperature 25°C (77°F)	1.9 to 2.1 kΩ
2 (TBS) – 3 (TB5)	Controller temperature 30°C (86°F)	1.6 to 1.7 kΩ

**HINT:**

As the temperature increases, the resistance decreases.  
If the result is not as specified, replace the controller.



**6. INSPECT SEAT CLIMATE CONTROLLER RH (FRONT SEATBACK)**

- (a) Measure the resistance between the terminals.

**Standard:**

Tester Connection	Condition	Specified Condition
4 (TDB-) – 5 (TDB+)	Constant	Below 1 Ω

If the result is not as specified, replace the controller.

- (b) Measure the thermistor resistance between the terminals.



**Standard:**

Tester Connection	Condition	Specified Condition
2 (TBS) – 3 (TB5)	Controller temperature 10°C (50°F)	3.6 to 3.8 kΩ
2 (TBS) – 3 (TB5)	Controller temperature 25°C (77°F)	1.9 to 2.1 kΩ
2 (TBS) – 3 (TB5)	Controller temperature 30°C (86°F)	1.6 to 1.7 kΩ

**HINT:**

As the temperature increases, the resistance decreases.  
If the result is not as specified, replace the controller.

Climate Control Seat Switch LH (Rear)



P

B77680

## 7. INSPECT CLIMATE CONTROL SEAT SWITCH LH (REAR)

- (a) Measure the resistance between the terminals when the switch is operated.

### Standard:

Tester Connection	Condition	Specified Condition
10 (VSL) – 13 (V5L)	Switch ON (LH) Max.COOL to Max.WARM	Below 1 to 5 kΩ
11 (SWL) – 8 (E)	ON	Below 1 Ω
11 (SWL) – 8 (E)	OFF	10 kΩ or higher

### HINT:

As the dial is being turned, the resistance changes gradually. If the result is not as specified, replace the seat heater switch.



- (b) Check that the seat heater switch indicator illuminates.

### OK:

Measurement Condition	Condition	Specified Condition
Battery positive (+) → Terminal 7 (ILL+) Battery negative (-) → Terminal 8 (E)	Constant	Illuminates
Battery positive (+) → Terminal 12 (INDL) Battery negative (-) → Terminal 8 (E)	Constant	Illuminates

If the result is not as specified, replace the switch or bulb.

Climate Control Seat Switch LH (Rear)



P

B78654

## 8. INSPECT CLIMATE CONTROL SEAT SWITCH RH (REAR)

- (a) Measure the resistance between the terminals when the switch is operated.

### Standard:

Tester Connection	Condition	Specified Condition
3 (VSR) – 6 (V5R)	Switch ON (RH) Max.COOL to Max.WARM	Below 1 Ω to 5 kΩ
4 (SWR) – 8 (E)	ON	Below 1 Ω
4 (SWR) – 8 (E)	OFF	10 kΩ or higher

### HINT:


As the dial is being turned, the resistance changes gradually. If the result is not as specified, replace the seat heater switch.

- (b) Check that the seat heater switch indicator illuminates.

### OK:

Measurement Condition	Condition	Specified Condition
Battery positive (+) → Terminal 7 (ILL+) Battery negative (-) → Terminal 8 (E)	Constant	Illuminates
Battery positive (+) → Terminal 12 (INDR) Battery negative (-) → Terminal 8 (E)	Constant	Illuminates


If the result is not as specified, replace the switch or bulb.



### 9. INSPECT SEAT CLIMATE CONTROL BLOWER LH (REAR SEAT CUSHION)

- (a) Connect the battery's positive (+) lead to terminals 3 (BCS) and 4 (BFC-), and the negative (-) lead to terminal 2 (BFC+). Check that the blower fan motor operates smoothly.


If the result is not as specified, replace the blower fan motor.



### 10. INSPECT SEAT CLIMATE CONTROL BLOWER RH (REAR SEAT CUSHION)

- (a) Connect the battery's positive (+) lead to terminals 3 (BCS) and 4 (BFC-), and the negative (-) lead to terminal 2 (BFC+). Check that the blower fan motor operates smoothly.

If the result is not as specified, replace the blower fan motor.



### 11. INSPECT SEAT CLIMATE CONTROLLER LH (REAR SEAT CUSHION)

- (a) Measure the resistance between the terminals when the switch is operated.

#### Standard:

Tester Connection	Condition	Specified Condition
4 (TDB-) - 5 (TDB+)	Constant	Below 1 $\Omega$

If the result is not as specified, replace the controller.

- (b) Measure the thermistor resistance between the terminals.

#### Standard:


Tester Connection	Condition	Specified Condition
2 (TCS) - 3 (TC5)	Controller temperature 10°C (50°F)	3.6 to 3.8 k $\Omega$
2 (TCS) - 3 (TC5)	Controller temperature 25°C (77°F)	1.9 to 2.1 k $\Omega$
2 (TCS) - 3 (TC5)	Controller temperature 30°C (86°F)	1.6 to 1.7 k $\Omega$

#### HINT:

As the temperature increases, the resistance decreases.

If the result is not as specified, replace the controller.

### Seat Climate Controller RH (Rear Seat Cushion)



B77686

## 12. INSPECT SEAT CLIMATE CONTROLLER RH (REAR SEAT CUSHION)

- (a) Measure the resistance between the terminals when the switch is operated.

### Standard:

Tester Connection	Condition	Specified Condition
4 (TDC-) – 5 (TDC+)	Constant	Below 1 $\Omega$

If the result is not as specified, replace the controller.

- (b) Measure the thermistor resistance between the terminals

### Standard:


Tester Connection	Condition	Specified Condition
2 (TCS) – 3 (TC5)	Controller temperature 10°C (50°F)	3.6 to 3.8 k $\Omega$
2 (TCS) – 3 (TC5)	Controller temperature 25°C (77°F)	1.9 to 2.1 k $\Omega$
2 (TCS) – 3 (TC5)	Controller temperature 30°C (86°F)	1.6 to 1.7 k $\Omega$

### HINT:

As the temperature increases, the resistance decreases.

If the result is not as specified, replace the controller.

### Blower Fan Motor



T


B78647

## 13. INSPECT SEAT CLIMATE CONTROL BLOWER LH (REAR SEATBACK)

- (a) Connect the battery's positive (+) lead to terminals 3 (BBS) and 4 (BFB-), and the negative (-) lead to terminal 2 (BFB+). Check that the blower fan motor operates smoothly.

If the result is not as specified, replace the blower fan motor.

### Blower Fan Motor



T


B78647

## 14. INSPECT SEAT CLIMATE CONTROL BLOWER RH (REAR SEATBACK)

- (a) Connect the battery's positive (+) lead to terminals 3 (BBS) and 4 (BFB-), and the negative (-) lead to terminal 2 (BFB+). Check that the blower fan motor operates smoothly.

If the result is not as specified, replace the blower fan motor.

### Seat Climate Controller LH (Rear Seatback)



B77686

## 15. INSPECT SEAT CLIMATE CONTROLLER LH (REAR SEATBACK)

- (a) Measure the resistance between the terminals when the switch is operated.

### Standard:

Tester Connection	Condition	Specified Condition
4 (TDB-) – 5 (TDB+)	Constant	Below 1 $\Omega$

If the result is not as specified, replace the controller.


- (b) Measure the thermistor resistance between the terminals  
**Standard:**

Tester Connection	Condition	Specified Condition
2 (TBS) – 3 (TB5)	Controller temperature 10°C (50°F)	3.6 to 3.8 kΩ
2 (TBS) – 3 (TB5)	Controller temperature 25°C (77°F)	1.9 to 2.1 kΩ
2 (TBS) – 3 (TB5)	Controller temperature 30°C (86°F)	1.6 to 1.7 kΩ

**HINT:**

As the temperature increases, the resistance decreases.  
 If the result is not as specified, replace the controller.

Seat Climate Controller RH  
 (Rear Seatback)



B77686

#### 16. INSPECT SEAT CLIMATE CONTROLLER RH (REAR SEATBACK)

- (a) Measure the resistance between the terminals when the switch is operated.

**Standard:**

Tester Connection	Condition	Specified Condition
4 (TDB-) – 5 (TDB+)	Constant	Below 1 Ω

If the result is not as specified, replace the controller.

- (b) Measure the thermistor resistance between the terminals.


**Standard:**

Tester Connection	Condition	Specified Condition
2 (TBS) – 3 (TB5)	Controller temperature 10°C (50°F)	3.6 to 3.8 kΩ
2 (TBS) – 3 (TB5)	Controller temperature 25°C (77°F)	1.9 to 2.1 kΩ
2 (TBS) – 3 (TB5)	Controller temperature 30°C (86°F)	1.6 to 1.7 kΩ

**HINT:**

As the temperature increases, the resistance decreases.  
 If the result is not as specified, replace the controller.

Rear Wing Outer Heater LH



B30883

#### 17. INSPECT REAR SEAT CUSHION HEATER ASSY LH


- (a) Measure the resistance between the terminals of the rear wing outer heater LH.

**Standard:**

Tester Connection	Condition	Specified Condition
1 – 2	20°C (68°F)	2.8 to 3.4 Ω

If the result is not as specified, replace the rear wing outer heater assy LH.

Rear Wing Inner Heater LH



B30883

- (b) Measure the resistance between the terminals of the rear wing inner heater LH.


**Standard:**

Tester Connection	Condition	Specified Condition
1 - 2	20°C (68°F)	7.2 to 8.8 Ω


If the result is not as specified, replace the rear wing inner heater assy LH.

Rear Cushion Heater LH


Rear Wing  
Inner Side



Rear Wing  
Inner Side



Rear Back side



B78956

- (c) Measure the resistance between the terminals of the rear cushion heater LH.


**Standard:**

Tester Connection	Condition	Specified Condition
A1 - B1	20°C (68°F)	4.2 to 5.1 Ω
C2 - C4	20°C (68°F)	4.2 to 5.1 Ω
A2 - B2	Constant	Below 1 Ω
C1 - C3	25°C (77°F)	2 kΩ


If the result is not as specified, replace the rear cushion heater assy LH.

Rear Seatback Heater LH

Rear Cushion Side  
A



S61  
Female Connector



B78954

**18. INSPECT REAR SEATBACK HEATER ASSY LH**

- (a) Measure the resistance between the terminals of the rear seatback heater LH.


**Standard:**

Tester Connection	Condition	Specified Condition
A2 - A4	20°C (68°F)	5.4 to 6.6 Ω
S60-4 - A2	20°C (68°F)	5.4 to 6.6 Ω
S60-2 - A4	20°C (68°F)	5.4 to 6.6 Ω
S60-1 - A1	Constant	Below 1 Ω
S60-3 - A3	Constant	Below 1 Ω

If the result is not as specified, replace the rear seatback heater assy LH.



Rear Wing Outer Heater RH



B30883

19. INSPECT REAR SEAT CUSHION HEATER ASSY RH


- (a) Measure the resistance between the terminals of the rear wing outer heater RH.

Standard:

Tester Connection	Condition	Specified Condition
1 – 2	20°C (68°F)	2.8 to 3.4 Ω

If the result is not as specified, replace the rear wing outer heater assy RH.

Rear Wing Inner Heater RH



B30883

- (b) Measure the resistance between the terminals of the rear wing inner heater RH.


Standard:

Tester Connection	Condition	Specified Condition
1 – 2	20°C (68°F)	7.2 to 8.8 Ω


If the result is not as specified, replace the rear wing inner heater assy RH.

Rear Cushion Heater RH


Rear Wing  
Inner Side



Rear Wing  
Inner Side



Rear Back Side  
C




B78956

- (c) Check the resistance between the terminals of the rear cushion heater RH.

Standard:

Tester Connection	Condition	Specified Condition
A1 – B1	20°C (68°F)	4.2 to 5.1 Ω
C2 – C4	20°C (68°F)	4.2 to 5.1 Ω
A2 – B2	Constant	Below 1 Ω
C1 – C3	25°C (77°F)	2 kΩ

If the result is not as specified, replace the rear cushion heater assy RH.



**20. INSPECT REAR SEATBACK HEATER ASSY RH**

- (a) Measure the resistance between the terminals of the rear seatback heater RH.

**Standard:**

Tester Connection	Condition	Specified Condition
A2 - A4	20°C (68°F)	5.4 to 6.6 Ω
S61-4 - A2	20°C (68°F)	5.4 to 6.6 Ω
S61-2 - A4	20°C (68°F)	5.4 to 6.6 Ω
S61-1 - A1	Constant	Below 1 Ω
S61-3 - A3	Constant	Below 1 Ω

If the result is not as specified, replace the rear seatback heater assy RH.