


VARIABLE RESISTOR INSPECTION


FI0YJ-01

1. REMOVE VARIABLE RESISTOR



2. INSPECT POWER SOURCE VOLTAGE OF VARIABLE RESISTOR

- Disconnect the variable resistor connector.
- Turn the ignition switch ON.
- Using a voltmeter, VCC and E2 of the wiring harness side.
Voltage: 4.5 – 5.5 V
- Reconnect the variable resistor connector.




3. INSPECT POWER OUTPUT OF VARIABLE RESISTOR

- Turn the ignition switch ON.
- Connect a voltmeter to terminals VAF and ETA of the ECU, and measure the voltage while slowly turning the idle mixture adjusting screw first fully counter-clockwise, and then fully clockwise using SST.
SST 09243-00020
- Check that voltage changes smoothly from 0 V to approx. 5 V.

HINT:


There is no sudden jump up to 5 V or down to 0V.



4. INSPECT RESISTANCE OF VARIABLE RESISTOR

- Disconnect the variable resistor connector
- Using an ohmmeter, measure the resistance between terminals VCC and E2 of the variable resistor.

Resistance: 4 – 6 kΩ



- (c) Using SST, turn the idle mixture adjusting screw fully counterclockwise .
SST 09243-00020
- (d) Connect the ohmmeter to terminals VAF and E2 of the variable resistor, and turn the idle mixture adjusting screw fully clockwise and check that the resistance value changes from approx. 5 k Ω to 0 Ω accordingly.
- (e) Reconnect the variable resistor connector.