

## INSTALLATION

### 1. INSTALL GASKET

- (a) Clean the engine ECU's seal surface to the gasket with non-residue solvent.
- (b) Attach the gasket on the engine ECU.

### 2. INSTALL ENGINE ECU

Install the engine ECU with 2 nuts.

**Torque: 5.5 N·m (56 kgf·cm, 49 in·lbf)**

### 3. CONNECT 5 CONNECTORS

### 4. INSTALL ECU COVER