

# TROUBLESHOOTING

## PROBLEM SYMPTOMS TABLE

PR029-01

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

Symptom	Suspect Area	See page
Noise	1. Center bearing (Worn)	<a href="#">PR-5</a>
	2. Sleeve yoke spline (Worn)	–
	3. Spider bearing (Worn or stuck)	<a href="#">PR-6</a>
	4. Flexible coupling (Worn)	<a href="#">PR-5</a>
Vibration	1. Transmission extension housing rear bushing (Worn)	–
	2. Flexible coupling (Worn)	<a href="#">PR-5</a>
	3. Sleeve yoke spline (Stuck)	–
	4. Propeller shaft (Runout)	<a href="#">PR-6</a>
	5. Propeller shaft (Imbalance)	–