



SLIDING ROOF ON-VEHICLE INSPECTION

B00M1-05

INSPECT SLIDING ROOF GLASS ALIGNMENT

- (a) Start the engine and check the operation time of the sliding roof.

Operation time:

Approx. 6 secs.

- (b) Check for abnormal noise or binding during operation.
(c) With the sliding roof fully closed, check for water leakage.
(d) Check for a difference in level between the sliding roof weatherstrip and roof panel.

Front end:

– 1.5 mm (– 0.059 in.)

+ 0.5 mm (+ 0.020 in.)

Side end:

± 1.0 mm (± 0.039 in.)

Rear end:

– 0.5 mm (– 0.020 in.)

+ 1.5 mm (+ 0.059 in.)