

PROBLEM SYMPTOMS TABLE

If a normal system code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

HINT:

Inspect the "Fuse" and "Relay" before confirming the suspected areas as shown in the chart below.

Inspect each malfunction circuit in numerical order for the corresponding symptom.

Symptom	Suspected Area	See page
Main switch cannot be turned ON. (Cruise indicator light in combination meter does not come on.)	3. Cruise control switch circuit 4. CRUISE main indicator light circuit 5. ECM	05-3610 05-3615 10-21
Vehicle speed setting cannot be done. (Although indicator light in combination meter comes on when the main switch is turned ON, it goes off when vehicle speed is set.)	1. Cruise control switch circuit 2. ECM	05-3610 10-21
Setting cannot be done. (Indicator light in combination meter comes on when the main switch is turned ON and they remain ON while setting.)	1. Cruise control switch circuit 2. Stop lamp switch circuit 3. Park/neutral position switch circuit (DTC P0705) 4. Transmission control switch circuit 5. Combination meter system 6. ECM	05-3610 05-3601 05-563 05-642 05-2148 10-21
While the vehicle is driven with cruise control, the set control is cancelled. (Indicator light and CRUISE remain ON.)	1. Cruise control switch circuit 2. Vehicle speed sensor circuit 3. Stop lamp switch circuit 4. CRUISE main indicator light circuit 5. Park/neutral position switch circuit (DTC P0705) 6. ECM	05-3610 05-172 05-3601 05-3615 05-563 10-21
Hunting (Speed is not constant.)	1. Vehicle speed sensor circuit 2. ECM	05-172 10-21
Setting cannot be cancelled. (When Coast, Acceleration, Resume, Set speed change and Control switch are operated.)	1. Cruise control switch circuit 2. ECM	05-3610 10-21
DTC is not output, or is output when should not be.	1. Diagnosis circuit 2. ECM	05-3616 10-21
CRUISE MAIN indicator light does not come on.	1. Cruise control switch circuit 2. CRUISE main indicator light circuit 3. ECM 4. Combination meter assy	05-3610 05-3615 10-21 71-6